


IMPORTANT: THIS MANUAL MUST BE KEPT NEAR THE FURNACE FOR FUTURE REFERENCE!!




G95V


NATURAL AND PROPANE GAS TWO STAGE HIGH EFFICIENCY (CONDENSING) WARM AIR FURNACE




Installation, Operation & Maintenance Manual 240006743 REV E [04/2012]



User's Information Manual 240006752 REV D [04/2012]



Limited Warranty 240005038 REV A



Warranty Registration 1595023 REV B