

ECR97 USER INTERFACE KIT

INSTRUCTIONS

ECR97 - 075/100 Kit #550002201

WARNING

Kit shall be installed by qualified service agency in accordance with manufacturer's instructions and all applicable codes and requirements of authority having jurisdiction. If information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. Qualified service agency is responsible for proper installation of this kit. Installation is not proper and complete until operation of appliance is checked as specified in manufacturer's instructions supplied with the kit.

User Interface Kit:

1. Tools required:
 - Small slotted screwdriver
 - 1/4" nut driver
2. Follow instructions To Turn Off Gas to Appliance. Turn service switch to OFF position.
3. Remove jacket from boiler. Grasp front cover at lip behind plastic smoke-colored control cover. Pull forward to release snap action latches. Lift jacket up and off bottom jacket rest.
4. With one hand, grasp User Interface at top and bottom. Squeeze to depress bottom tab while lifting bottom of User Interface. User Interface is hinged at top and will release from bottom of base first. Swing up and off top hinges.
5. You may leave existing base in place and re-use - go to step 9.
6. Remove two wires from base connector, using small slotted screwdriver, if replacing interface base.
7. Remove two 8x1/2 base mounting screws with slotted screwdriver or 1/4" nut driver. Remove base.
8. Install new base using two 8x1/2 screws.
9. Attach two wires to connector. Wires are reversible.
10. Engage upper hinges, swing bottom down to latch onto base. Note: two pins engage base connector.
11. Turn service switch to ON position. Follow start-up instructions in Installation, Operation and Maintenance manual to restore and verify operation.
12. Re-attach jacket.


NOTICE

Verify proper operation after servicing.

Figure - 1 User Interface Overlay



Figure - 2 User Interface 2 Pin Connector



ISO 9001-2008 Certified Company

ECR International, Inc.

2201 Dwyer Ave.

Utica, NY 13501



PARTS LIST

ECR97 User Interface Kit #550002201		
DESCRIPTION	PART #	QTY
User Interface Control	-	1
Screw, 8x1/2 B, HWH, Slot, SZN	-	2
Instructions	240008602	1

Check our website frequently for updates: www.ecrinternational.com