

# **WIRING ADDENDUM**

## **15B Series with Hydrostat® Model 3200**


Temperature/LWCO Control with  
Thermal Targeting™  
for Water Boilers

For use with:


**Hydrostat®**

## **Model 3200 Installation Instructions and Operation Manual**

WIRING DIAGRAM - 24V STANDING PILOT




# WIRING DIAGRAM - INTERMITTENT IGNITION



## REPLACEMENT PARTS

### HYDROLEVEL - 15B



Item	Part No.	Description	Qty.
1	240009115	Well ¾" x 3"	1
2	240009113	Hydrolevel Control	1
3	1310001	Pipe - Nipple ¾" x 4"	1
4	VR-001.01	Relief Valve 30#	1
5	1190001	Pipe - Elbow ¾" 90°	1
6	1260006	Gauge - Theraltimeter	1
7	37519501	Harness Circulator 72"	1
8	1310002	Pipe - Nipple 1¼" x 4½" NPT	1
9	HW-016.03	Drain Valve	1

Item	Part No.	Description	Qty.
10	1516001	Pipe - Tee 1¼" x ¾" x 1¼"	1
11	240007093	Pilot Ignition Cable 30"	1
12	375-1-14.01	Wire - Low Voltage/Damper	1
13	37413602	Harness - Ignition to Gas Valve 18"	1
14	37513301	Wire - Rollout/Spill 28"	2
15	14662070	Pilot Spark Control	1
16	EF03601	Clamp #3600 White	2