## Instructions For Affixing Boiler Logo

- **1.** Peel protective paper backing off logo.
- **2.** Locate boiler logo on front of boiler above control as shown below.
- **3.** Logo should align with curvature of control bezel.





**ECR International, Inc.** 2201 Dwyer Avenue, Utica NY 13501 web site: www.ecrinternational.com