

IMPORTANT INSTRUCTIONS

READ BEFORE INSTALLATION

retain for future reference affix on or adjacent to the unit

INSTRUCTIONS IMPORTANTES

LIRE AVANT INSTALLATION

Pour La référence future apposer sur ou a cote l'unité

DANGER

Indicates a hazardous situation which, if not avoided, WILL result in death or serious injury.



ESC IV STEAM SERIES 4

OIL-FIRED CAST IRON BOILER

DANGER

Risk of carbon monoxide poisoning resulting in personal injury or loss of life.

Fuel burning equipment has a potential of producing lethal levels of Carbon Monoxide. To protect against carbon monoxide exposure, always,

1. Have your heating equipment installed by a heating professional
2. Have your heating equipment serviced annually by a heating professional
3. Install Carbon Monoxide detectors on all levels of your home

For more information pertaining to the effects and prevention of Carbon Monoxide poisoning, visit the Environmental Protection Agency website at <http://www.epa.gov/iaq/pubs/coftsht.html>, or email us at info@ecrinternational.com.

This envelope includes the following manuals:

- 240009804 ESFE IV Series 4 Installation, Operation & Maintenance Manual
- 240009808 ESFE IV Series 4 Parts Manual
- 240006274E Users Information Manual, Oil Boiler
- 240010365 Warranty Dunkirk Consolidated (REV D)
- 1595023 Warranty Registration Card

- Honeywell,L4006,L4007 Aquastat Controllers "TL" units only
- Instructions Pressuretrol PA 404A1074A/B
- Hydrolevel Cycle Guard CG450 Series
- Beckett AF/AFG Burner Manual



3002148

