

IMPORTANT INSTRUCTIONS

READ BEFORE INSTALLATION

retain for future reference affix on or adjacent to the unit

INSTRUCTIONS IMPORTANTES

LIRE AVANT INSTALLATION

Pour La référence future apposer sur ou a cote l'unité

DANGER

Indicates a hazardous situation which, if not avoided, WILL result in death or serious injury.



SW SERIES 2

OIL FIRED DIRECT EXHAUST CAST IRON BOILER

DANGER

Risk of carbon monoxide poisoning resulting in personal injury or loss of life.

Fuel burning equipment has a potential of producing lethal levels of Carbon Monoxide. To protect against carbon monoxide exposure, always,

1. Have your heating equipment installed by a heating professional
2. Have your heating equipment serviced annually by a heating professional
3. Install Carbon Monoxide detectors on all levels of your home

For more information pertaining to the effects and prevention of Carbon Monoxide poisoning, visit the Environmental Protection Agency website at <http://www.epa.gov/iaq/pubs/coftsht.html>, or email us at info@ecrinternational.com.

This envelope includes the following manuals:

- 240009678 SW Series 2 Installation, Operation & Maintenance Manual
- 240009677 SW Series 2 Parts Manual
- 240006274E Users Information Manual, Oil Boiler
- 240010431 Warranty, Consolidated UB (REV D)
- 1595023 Warranty Registration Card
- 240009623 2012 Compliance Statement
- 27515501 Venting Addendum
- 240005929 Addendum Safety Direct Vent, SWV
- 240006453 Addendum Venting SW

Honeywell, L7224A, C; L7248A, C, L, Oil Electronic Aquastat, Controllers (CO) versions only

Honeywell L8124A, C, E, L and M Aquastat Relays (TL) versions only

Beckett AFII Oil Burner Manual (BDV Versions only)

Riello Model BF3 & BF5 Burner Manual (RDV Versions only)



3002153

