

Instructions

For Affixing Boiler Logo

PN 3002210 REV E

1. Peel protective paper backing off logo.
2. Locate boiler logo on front of boiler above control as shown below.
3. Logo should align with curvature of control bezel.

