IMPORTANT: THIS MANUAL MUST BE KEPT NEAR THE FURNACE FOR FUTURE REFERENCE!!





Oil Fired Warm Air Furnaces LRF/LRFV Lowboy Rear Flue

Airco Olsen
LRF Lowboy Rear Flue Model
LRFV Lowboy Rear Flue Model with ECM Blower
Oil Fired Warm Air Furnaces
INSTALLATION, OPERATION & MAINTENANCE MANUAL
ECR international

Homeowner Instructions
Fire, explosion, asphyxiation and electrical shock hazard. Improper installation and operation could result in death or serious injury. Read this manual and understand all
shock hazard. Improper installation and operation could result in death or serious injury. Read this manual and understand all
WARNING
Keep area clear and free from combustible materials; agooline and other flammable vapors and liquids. Do not stack, bowin; or store itense within the Do NOT obstruct air openings to the furnace room. Modification, substitution or elimination of factory equipped; supplied or specified or so of life. To THE OWRE - Installation and service of this appliance must be performed by a qualified installer. To Table of installer.
Save These Instructions For Reference

Installation, Operation & Maintenance Manual 240011511 REV E [03/15/2018]

User's Information Manual 240006450 REV C [03/15/2018]



[05/16/2016]

Limited Warranty 240005038 REV E [02/01/2017]

Envelope Assy Master 3002361 REV G [03/15/2018]