Instructions For Affixing Boiler Logo Kit 3002382 REV G

- 1. Peel protective paper backing off logo.
- 2. Locate boiler logo on front of boiler above control as shown below.
- **3.** Logo should align with curvature of control bezel.





Manufactured by: ECR International, Inc. 2201 Dwyer Avenue, Utica, NY 13501 Tel. 800 253 7900