



Utica SSC Training Seminar

Instructor:





Ratings & Capacities

Capacities BTUH	50,000	75,000	100,000	150,000	200,000	299,000
Modulation with 5 to 1 turndown	50,000 10,000	75,000 15,000	100,000 20,000	150,000 30,000	200,000 40,000	299,000 60,000
Nat or LP	LP c					
AFUE	95	95	95	95	94	94
Water Connections	1-1/4"	1-1/4"	1-1/4"	1-1/4"	1-1/4"	1-1/4"













2.4

Dimensions / Weights

		Model Size	50,000 75,000 100,000	150,000 200,000	299,000
		Width (A)	20"	23"	23"
	(B)	Height (B)	30"	40"	40"
		Depth (C)	14"	16"	18.3"
		Boiler Weights	<u>91 lb</u>	<u>157 lb</u>	<u>195 lb</u>
(C) (A)	<u> </u>				




- Vertical Stainless Steel Coil Heat Exchanger
- Probe-type low water cut-off
- Specialized flue collector designs
- Argus vision control
- Built-in Primary/Secondary Piping



Built In Pump & Piping

- Factory installed.
- Low pressure drop (less than ½ psi) across the boiler's supply and return connections.
- Hydraulically Separates boiler from the system.
- A ball valve is located between the closely spaced tees.



Benefits

Saves the installer material and labor.

No need to purchase a costly high head pump. Easy to connect to existing systems without extensive re-piping.


Ensures proper flow through the boiler's heat exchanger regardless of how many system zones are open or closed.

Increases the boiler's piping options when the existing system already has a set of closely spaced tees or when installing a new multiple boiler system.

Internal Piping




- Primary Secondary can be either internal to boiler or external to already existing closely spaced tee's!
- Saves both time and money on install
- Note: System requires at least one secondary circulator.





Built In Pump & Piping



Primary/Secondary Piping and Pump

Factory installed inside the boiler.

The internal pump provides the correct amount of water flow through the heat exchanger.

The pressure drop across the boiler's supply and return line is negligible the boiler is not adding resistance to the system piping.

Selling Installed Value

SSC Contractor Challenge

- Targeted Contractors who sell competitors MODCONs.
- When we compare price to price we are often equal, sometimes higher.
- When the filled out the Scorecard we found to be from \$343 to \$1700 LESS!!



and the second second	- DRONGER	17.0	training and the		U	VBOILERS
	/5	.1	Utica	SSC Cont	ractor Challenge Scorecard	
Date: Company Name:	10.12	-12-			Score Keeper Name:	
Street Address					Utica Representative:	
City, State, Zip:					ECR RSM:	
Phone:				_	Distributor:	
Email:	USTOM	C SECUL	LOUGAN	FLC VC	Com	
	Sec. Mill	der state	N. 196	Con	npetitor Scorecard	
	tive Condens anufacturer		We	1)r	Ichain Ultra 230	
ltem	Material Cost	Labor Hours	Labor Cost per Hour	Total Labor Cost	Description	Total Cost (Materia + Labor)
Cost of Competitive Boller	4221.87	17	150.	2,550.		6 ,171.87
Primary/ Secondary Piping	285.40	2	150	300.	Cost to purchase all piping, fittings, valves and materials to construct the P/S loop. Include the time, number of technicians and fully burdened labor rate to install.	585.40
Primary Pump (if not included)	278.48	- 1	150	150	Cost of primary pump and labor to install	428.48
Code Compliant LWCO (if applicable)					Cost of probe type LWCO	-
Electrician/Labor to install and wire LWCO					Cost of labor or sub-contracted electrician to wire and install LWCO	~
Wall Bracket						-
Productivity Rating					Total labor time required for installation start to finish (number of technicians x hours to complete)	20
					Total Cost:	7,785.75
Service March	and the second				SSC Scorecard	
		SSC				
Item	Material Cost	Labor Hours	Labor Cost per Hour	Total Labor Cost	Description	Total Cost (Materia + Labor)
SSC Cost	3,809.93	16	150	3,400.		6,209,93
Primary/ Secondary Piping		0			Cost to purchase all piping, fittings, valves and materials to construct the P/S loop. Include the time, number of technicians and fully burdened labor rate to install.	-
Primary Pump (if not included)					Cost of primary pump and labor to install	~
Code Compliant LWCO (if applicable)					Cost of probe type LWCO	-
Electrician/Labor to nstall and wire LWCO					Cost of labor or sub-contracted electrician to wire and install LWCO	ļ
Wall Bracket						<i>—</i>
					Total labor time required for installation start to finish (number of	. 1

\$1575.82



The SSC Contractor Challenge Scorecard

 Date:
 12/1/2012

 Company Name:
 Score Keeper Name:

 Street Address:
 Utica Representative:

 City, State, Zip:
 ECR RSM


 Phone:
 Distributor:

 Email:
 Email:

IV.	lanufacturer	and model				0007560.035
Item Cost of Competitive Boiler	Material Cost	Labor Hours	Labor Cost per Hour	Total Labor Cost	Description Weil Mc Clain Ultra	Total Cost (Material Labor)
Primary/ Secondary Piping	B185	ч	\$85		Cost to purchase all piping, fittings, valves and materials to construct the P/S loop. Include the time, number of technicians and fully burdened labor rate to install.	N 700
Primary Pump (if not included)	\$300				Cost of primary pump and labor to install	1 300
Code Compliant LWCO (if applicable)	ø				Cost of probe type LWCO	ø
Electrician/Labor to install and wire LWCO	ø				Cost of labor or sub-contracted electrician to wire and install LWCO	ø
Wall Bracket	¢					
Productivity Rating				i. V	Total labor time required for installation start to finish (number of technicians x hours to complete)	1200
					Total Cost:	\$ 6500

\$605.00

CAUNCA BOLLESS





Date	12/28/2	212				
Company Name:	12/00/0	Dia			Score Keeper Name:	
Street Address:	t				Utica Representative:	
City, State, Zip:	t				ECR RSM:	
Phone:	t				Distributor:	
Email:	t				Distributor.	
	L			-		
				OMPET	TITOR SCORECARD	
	titive Condens Ianufacturer a			A CONTRACT		
	Material	Labor	Contraction of	Total Labor	Description	Total Cost (Material +
Item	Cost	Hours	per Hour	Cost		Labor)
Cost of Competitive Boiler			\$80		Triangle Tube Prestige	\$3500
					9	She
Primary/ Secondary			-		Cost to purchase all piping, fittings, valves and materials to construct the P/S loop. Include the time, number of technicians and fully burdened labor rate to	. F
Piping	240	2	\$40		install.	\$ 400
Primary Pump (if not		-	-	· · · · ·	Cost of primary pump and labor to install	15
included)	925	.5	680	'	Cost of primary pump and labor to instan	\$ 145
Code Compliant LWCO (if applicable)	16	.5	\$80		Cost of probe type LWCO	\$100
Electrician/Labor to	a t	۲.	00	'		100
Electrician/Labor to install and wire LWCO					Cost of labor or sub-contracted electrician to wire and install LWCO	ø
Wall Bracket						6
Productivity Rating		12.	\$80		Total labor time required for installation start to finish (number of technicians x hours to complete)	\$960
					Total Cost:	5105
		1.00		SSC	C SCORECARD	
and the second second		SSC	1 Carrier	350	SCORECARD	
a set internet of the	-	-				
Item	Material Cost	Labor Hours	Labor Cost per Hour	Total Labor Cost	r Description	Total Cost (Material + Labor)
SSC Cost		1.5	\$ 80	There	55C 200	\$ 3842
And the second second second second	#80	.5	180		Cost to purchase all piping, fittings, valves and materials to construct the P/S loop. Include the time, number of technicians and fully burdened labor rate to install.	
Primary Pump (if not included)					Cost of primary pump and labor to install	¢
Code Compliant LWCO (if applicable)					Cost of probe type LWCO	¢
Electrician/Labor to install and wire LWCO					Cost of labor or sub-contracted electrician to wire and install LWCO	ø
Wall Bracket						ø
Productivity Rating		10	\$\$ 80		Total labor time required for installation start to finish (number of technicians x hours to complete)	\$ \$ 800

\$343.00



Selling Installed Valued – Contractor Testimonial

"We went form two men, two days to two men one day!" "We are still quoting and getting jobs with 2 men/2 days but are much more profitable, and competitive with the SSC and H2O"



Stainless Steel Coil Heat Exchanger

Vertical Helix Coil – Self Cleaning



- Stainless Steel Coil 316L with 444 fins that are laser welded to the coil.
- ASME "H" stamp with 150 MAWP
- Exclusive to ECR. Developed in our research facility located in Utica, NY

Benefits

Waterways are wide and smooth with a helix coil that expands and contracts to inhibit hard water scaling. The vertical design coil prevents debris from settling in the heat exchanger. Condensate flowing over the fins continually "washes" the combustion side

The stainless steel is resistant to the effects of acidic condensate. The laser welding process ensures the highest level of heat transfer and efficiency

Competitive advantages over other brands which do not have this heat exchanger technology.

H Stamped, ASME heat exchanger designed, assembled and independently audited in our Utica NY facility; unlike competitors who source their heat exchangers.



Heat Exchanger

- 316L/444 Stainless Steel Coil
- Wide open design
- No high head pump required
- Self cleaning action
- We live up to our claim





Stainless Steel Coil Heat Exchanger 299 Series









Stainless Steel Coil Heat Exchanger

SSC Heat Exchanger Construction

316L stainless steel tubing has 444 fins laser welded onto the tubing. 444 fins are used due to their high heat transfer and high corrosion resistance in the combustion area.

Tubing Diameter

The larger diameter tubing and round shape optimize water flow through the heat exchanger. Less restriction compared to other designs

Positioning / Self Cleaning

The vertical positioning of the coil heat exchanger and open fin spacing allows the heat exchanger to drain off any combustion particles. The natural flexing of the coil during operation reduces scale buildup

Self cleaning – both water and flue gas sides








Heat Exchanger Comparisons

Competition SSC Coil



SSC round shape with a larger diameter coil for better water flow and reduced scaling SSC Coil

Vertically positioned to drain away any debris and scale - self cleaning. Open flueways between the coils. Competition



Horizontal positioning - low spots where debris may settle. Close flueways between the coils. Oval shaped small diameter tubes restrict water flow



Heat Exchanger Comparisons



SSC Coil

Water Tube – Single piece coil Self Cleaning Flue Gas Side – Yes Water Side – Yes - water flow velocity is maintained preventing debris from settling. The natural flexing of the coil (during operation) reduces scale buildup 15 year HX warranty 5:1 turndown 95% AFUE 94% AFUE (200/299 sizes)

Vertically Positioned - yes Self Cleaning – (see below) Stainless Construction – yes



Competition

Fire Tube – Multiple tubes with welded connections potential stress and leak points

Self Cleaning
Flue Gas Side – Yes
Water Side – Water flow velocity is reduced allowing debris to settle inside the heat exchanger
10 year HX warranty
3.7:1 or 5:1 turndown – depending on manufacture

95% AFUE








- Worgas[™] designed gas burner
- Natural / propane
- Easy removal for field inspection
- Easy removal for maintenance to heat exchanger



Note: Burner is keyed to heat exchanger. Line up notch in heat exchanger casting.




Combustion Path





Gas Valve 50-200 Models






Don't touch offset screw Will void valve's calibration

- 120 volt gas valve system
- Venturi system takes air from within the sealed cabinet
- Adjust throttle screw for proper gas / air CO² setting




Gas Valve-299 model





Probe-Type Low Water Cutoff



Low Water Cutoff

- Protects the boiler.
- Factory installed.
- Probe style.
- Test button feature with indicator lights.

Benefits

Prevents boiler operation without the proper water level.

Saves the installer material and labor. Most States now require a boiler to have a low water cutoff.

Reliably operates off of the water level in the boiler and not a pressure or flow sensing device. This is not a surface mounted sensor.

Easy to test and verify the LWCO is operating properly.



Condensate Collector 50-200 models

Specialized Flue Collector

Schedule 40 CPVC (Changing to Polypropylene)

Exceptional resistance to the effects of acidic condensate.

Will not corrode over the life of the boiler.

Saves the installer material and labor.





Condensate Collector 299 model

Benefits

Polypropylene – High temperature rating.

Exceptional resistance to the effects of acidic condensate.

Will not corrode over the life of the boiler.

Flue Gas sample port built in.







Condensate Drain

- Drain is ³/₄" PVC NPT.
- Internal trap built into boiler drain.
- Fill trap with water prior to start of boiler.
- Contractor is required to run a drain off boiler.





Control Package ARGUS™ Vision



ARGUS™ Control EASY TO PROGRAM EASY TO UNDERSTAND

Same Control on 50-299 models!



Installation



Combustible Clearances



Boiler Clearances						
Dimension	Combustible Materials (1)	Service (1) (2)				
Model	050 / 075 / 100 / 150 / 200 / 299	050 / 075 / 100 / 150 / 200 / 299				
Тор	0" (0 cm)	14" (36 cm)				
Left Side	0" (0 cm)	0" (0 cm)				
Right Side	0" (0 cm)	0" (0 cm)				
Front	0" (0 cm)	6" (16 cm)				
Back	0" (0 cm)	0" (0 cm)				
Bottom	0" (0 cm)	12" (32 cm)				
Combustion Air/Vent Piping	0" (0 cm)	6" (16 cm)				
Hot Water Piping	1/2" (1.3 cm)	6" (16 cm)				
(1) Required distances measured from boiler.						
(2) Service, proper operation clearance recommendation.						





- Access to outdoors to meet minimum and maximum pipe lengths
- Disposal of condensate
- Drainage of water or anti-freeze during service or from safety relief valve piping
- Access to system water, gas piping and electrical service
- Ambient room location above 32°F
- Approved for installation in a closet
- Protect boiler from any external water or moisture that could damage the electrical or combustion controls



Hanging The Boiler



Wall Mount Bracket and Hardware Included

Note: For Multiple Boiler Applications - Boilers can be placed side by side or back to back



Floor Stand Features Include:

- Powder Coated Black Paint with a textured finish to match the boiler back panel. The paint process provides a durable rust resistant finish.
- One size floor stand fits the entire SSC condensing family from 50 through 299 mbh.
- The stand is shipped in a knockdown configuration for ease of handling and transport. The stand can be quickly assembled at the jobsite in just a few minutes.





Boiler Connections

- Bottom Supply and Return 1-1/4" NPT
- Fuel Inlet 1/2" NPT 50-75-100


³/₄" 150 – 200 - 299

- Condensate Drain ³/₄" NPT
- Combustion Air & Vent 2" or 3"
- ¾" NPT Stub out on top for field installation of Safety Relief & Air Vent (included with Boiler)





<u>Top View</u>



Bottom View



Top Trim-Relief Valve / Air Vent



Rated up to 150 MAWP

- Factory supplied 30 psig relief valve
- Install safety relief valve and air vent using pipe fittings provided with the boiler
- Install ³/₄" or larger discharge pipe to floor
- Install relief valve with spindle in vertical position only
- Do not install shutoff valve between boiler and safety relief valve
- Field Installed pipe relief valve to within 6" of floor



Trimming the Boiler



Included with every Boiler is a complete Trim kit!

No need to purchase anything additional.



Bottom Trim-T\P Gauge & Drain



On the water side, the only thing left to connect is your Supply & Return !







- Gas piping needs to be in accordance with all national and local codes
- Flexible gas line piping and gas shut off inside of boiler
- Always check gas piping and connections for leaks



½" NPT Gas Connection 50/75/100
¾" NPT Gas Connection 150/200/299
Use a backup wrench when tightening







- Service shut off valve inside boiler
- Shut off valve still required <u>external</u> of the boiler





Gas Supply Pressure				
Capacities BTUH	Natura	al Gas	Propane	
	Min.	Max.	Min.	Max.
50,000 - 299,000	*3.0" w.c. (0.7kPa)	13.5" w.c. (3.3 kPa)	5.0" w.c. (1.2 kPa)	13.5" w.c. (3.4 kPa)

*Minimum gas pressure requirement of 3" w.c. – excellent for metropolitan areas with low gas pressure from the utility.



LP Gas Conversion

- All boilers shipped as Nat Gas. LP Kit included.
- Propane orifice conversion from natural gas in less than 5 minutes.
- Orifice to be installed for propane gas fired units
- <u>Propane gas</u> supply inlet pressures: 5" w.c. minimum, 13.5" w.c. maximum






Propane orifice location 50-200



LP Gas Conversion



Propane orifice - 299



Electrical Connections Line Voltage

- Wiring connections located inside, bottom left
- Incoming 120 volt
- Central heating circulator pump
- Domestic hot water circulator pump








Electrical Connections Line Voltage

Table 11 – Maximum Allowable Current Draw


МВН	CH PUMP	DHW PUMP	NOTE
50 75 100 150 200	1 A	1 A	Powered by Control Board
299	10 A	10 A	Powered by installed 10 Amp relay
If CH or DHW pump current is more than the maximum allowable current draw install proper field sourced relays as shown in figure 8-3.			

Figure 8-3 Isolation Relays for CH System Pump and DHW Pump









Built-in Pump Relay is provided on the 299 model.

Pending Change - 150 & 200 models will also incorporate the pump relay.




Electrical Connections Low Voltage

Low voltage terminal strip located inside boiler

Connections

- User Interface
- •ARGUS™ Link
- Sensors
- •TT DHW / CH
- •Removable for easy wiring





299

50-200

CAUTICA BOILERS One Zone Heat and/or Indirect DHW






Table 11 – Maximum Allowable Current Draw



ERS



Outdoor air sensor


ERS




If done with the SSC It will be **INCORRECT – WHY?**

HINT:

Installed in December and it worked fine until this spring




Outdoor air sensor



ERS


Argo AR822II can be used as isolation relay.

CORRECT






Using AR822 with ARM Control





System Wiring Zone Valves



End Switch of DHW Zone Valve acts as DHW Signal

ARGO AZ-4CP



Multiple Boiler System

- ARGUS [™] control on first boiler will act as the master control. Requires a Multiple Boiler Install Kit p/n 550002186
- Only \$76 List
- No need for expensive MBS control

Wiring

Daisy chain wiring from the master to additional boilers with low voltage wiring from the ARGUS link terminals (2-conductor low voltage wire)



Multiple Boiler Piping




FIGURE 5-8A Multiple Boiler Two Pipe Zoned System With Zone Valves - (See Multiple Boiler Guide)



Venting / Combustion Air



Combustion Air and Vent Pipe Equivalent Length					
Model 2" Pipe		e 3" Pipe			4" Pipe
050	075/100	075/100	150/200	299	299
6 ft. (1.8 m)	6 ft. (1.8 m)	6 ft. (1.8 m)	6 ft. (1.8 m)	6 ft. (1.8 m)	6 ft. (1.8 m)
100 ft. (30.5 m)	50 ft. (15.2 m)	100 ft. (30.5 m)	100 ft. (30.5 m)	25 ft. (7.7 m)	100 ft. (30.5 m)
	2" 050 6 ft. (1.8 m) 100 ft.	050 075/100 6 ft. (1.8 m) 6 ft. (1.8 m) 100 ft. 50 ft.	2" Pipe 050 075/100 075/100 6 ft. (1.8 m) 6 ft. (1.8 m) 6 ft. (1.8 m) 100 ft. 50 ft. 100 ft.	050 075/100 075/100 150/200 6 ft. (1.8 m) 6 ft. (1.8 m) 6 ft. (1.8 m) 6 ft. (1.8 m) 100 ft. 50 ft. 100 ft. 100 ft.	2" Pipe 3" Pipe 050 075/100 075/100 150/200 299 6 ft. (1.8 m) 100 ft. 50 ft. 100 ft. 100 ft. 25 ft.

1 - 90° elbow = 5 ft. (1.6 m)

1 – 2" x 3" adapter = 0 ft. (0 m)

Note: Concentric Vent Kit = 5 ft. (1.6 m) equivalent length

i.e.: Boiler can be installed on outside wall and vented with 1 - 90° elbow and 1 ft. (0.30m) of vent pipe.



- Venting to ANSI 223.1 / NFPA 54 standards
- Material PVC / CPVC / Polypropylene, refer to IOM for additional approved vent materials and pipe schedules
- No cellular (foam core) pipe
- Utilize proper cleaner and glue
- Termination two (2) pipe or concentric venting system



Venting / Combustion Air


- PVC
- CPVC
- ABS
- Polypropylene

Table 4 – Combustion air and vent pipe fittings must conform with the following:		
Item	Material	Standards
Vent Pipe and Fittings	PVC schedule 40	ANSI/ASTM D1785
	PVC – DWV	ANSI/ASTM D2665
	CPVC schedule 40	ANSI/ASTM D1784/F441
	SDR-21 & SDR-26 PVC	ANSI/ASTM D2241
	ABS-DWV	ANSI/ASTM D2661
	Schedule 40ABS	ANSI/ASTM F627
	PP (Polypropylene) Pipe and Components	UL 1738 ULC S636-08
	PVC	ANSI/ASTM D2564
Pipe Cement / Primer	CPVC	ANSI/ASTM F493
	Schedule 40 ABS	ANSI/ASTM D2235
 IPEX is approved vent manufacturer in Canada listed to ULC-S636. IPEX System 636 Cements and Primers are approved in Canada listed to ULC-S636 		

Use of cellular core PVC (ASTM F891), cellular core CPVC, or Radel®, (Polyphenolsulfone) in venting systems shall be prohibited.



Venting Configurations



Roof w/ Concentric combustion air

Roof w/ sidewall combustion air

Roof w/ inside combustion air



Venting Configurations




Vent Combustion Air 12" (305mm) Anticipated Snow Line Ground Level

Sidewall vent w/ combustion air on roof

Sidewall vent w/ inside combustion air










Venting Configurations

12" (305mm) Minimum From Overhang 3" (80mm) Minimum Separation 12" (305mm) Separation Between Bottom Of Combustion Air Intake And Bottom Of Vent Vent Page 22

FIGURE 6-2 Two Pipe Side Wall Vent

FIGURE 6-3 Two Pipe Side Wall Vent (Multiple Appliances.





Common Venting

Table 9 – Common Venting Pipe Diameters


Total Minimum Minimum Note: Flow Check Valve accessory Firing Diameter of **Diameter of Common vent** Common vent Rate pipes if L <50 ft pipes if L >50 ft required – kit number 240010299 (16m) (16m) 400 4" (101mm) 5"(127mm) 600 5"(127mm) 6"(152mm) 800 FIGURE 6-17 Mulitple Boilers With Common Venting Pipe 1000 1200 6"(152mm) 7"(177mm) /ent 1400 Combustion 1600 Air H 1800 7"(177mm) 8"(203mm) Flow Check **Flow Check** Flow Check Valve Valve -Valve 2000 12" (305mm) Anticipated Snow Line Ground Level



- Side wall or roof venting systems allowed
- 1' from or below doors, windows / gravity inlets <u>except</u> when using indoor air for combustion. 4' clearance required for single pipe installations. Direct vent on common wall <u>only</u>
- 3' above and 10' from any forced air inlet
- Above expected Snow grade (12")
- 3' from a inside "L" corner
- 4' horizontally from, no case above or below electrical, gas meter / regulators or relief equipment
- Cannot be vented under a deck or porch



Built In Pump & Piping




Primary/Secondary Piping and Pump

Factory installed inside the boiler.

The internal pump provides the correct amount of water flow through the heat exchanger.


The pressure drop across the boiler's supply and return line is negligible the boiler is not adding resistance to the system piping.





Boiler is shipped with the heat exchanger ball valve open. Connect to existing systems without extensive re-piping or the need to purchase a high head pump.

External Primary/Secondary Piping



LERS



Multiple Boiler Piping





FIGURE 5-8A Multiple Boiler Two Pipe Zoned System With Zone Valves - (See Multiple Boiler Guide)



Control Package ARGUS™ Vision

- ARGUS[™]
- Display / mother board
- Fuse protected
- Status Lights








Control Package ARGUS™ Vision

- Key Features:
 - User Interface with full text readout of error codes + diagnostics.
 - Integrated Multiple boiler control w/ simplified physical connection.









Boiler operates in standby mode until demand for Central Heat (CH) or Domestic Hot Water (DHW) is detected.



Control Display

Boiler Status Indicator

- F = Flame Detected
- P = Boiler Pump On
- B = Combustion Air Blower
- S = Spark Ignition On
- G = Gas Valve Open
- D = DHW Pump On



Service Reminder Indicator Boiler in Standby Mode Boiler Supply Water Temperature Indicator



Control Program




ARGUS™ Control

Кеу	Description
RESET	Reset Control / System
MENU	Enter / Exit user menu
ENTER	Select Menu item
	Confirm new parameter value
	Scroll up to next menu item
	Go to next screen
PLUS	Increase value
	Scroll down to next menu item
▼	Go to previous screen
MINUS	Decrease value

EASY TO PROGRAM EASY TO UNDERSTAND

TWO MENU'S: MAIN MENU & INSTALLERS MENU





Key	Description				
RESET	Reset Control / System				
MENU	Enter / Exit user menu				
ENTER	Select Menu item				
	Confirm new parameter value				
	Scroll up to next menu item				
A	Go to next screen				
PLUS	Increase value				
	Scroll down to next menu item				
▼	Go to previous screen				
MINUS	Decrease value				

Boiler Status Supply Temperature Setpoint Supply Temperature **Return Temperature** DHW Status System (Sensor) N.C. (Not Connected) Flue Temperature **Outside Air Temperature Boiler Pump CH/System Pump** DHW Pump



Main Menu	Outdoor Sensor	Outdoor Sensor		
Boiler Status	Settings	Settings		
Settings –	CH Setpoint	OD Reset (Not Adjustable)		
	DHW Setpoint	DHW Setpoint		
	Change Units °F/°C	Change Units °F/°C		

Кеу	Description
RESET	Reset Control / System
MENU	Enter / Exit user menu
ENTER	Select Menu item
	Confirm new parameter value
	Scroll up to next menu item
A	Go to next screen
PLUS	Increase value
	Scroll down to next menu item
▼	Go to previous screen
MINUS	Decrease value

Sample Screen Display

S	Ε	Т	Т		Ν	G	S											
	С	е	n	t	r	a	I		H	е	a	t	i	n	g			
	S	e	t	p	0	i	n	t					1	40		0		



(Menu & Enter Buttons – 4 seconds)

Installer Menu

Boiler Status

Boiler Config

CH Settings

DHW Settings

Cascade Settings

System Test

Кеу	Description
RESET	Reset Control / System
MENU	Enter / Exit user menu
ENTER	Select Menu item
	Confirm new parameter value
	Scroll up to next menu item
A	Go to next screen
PLUS	Increase value
	Scroll down to next menu item
▼	Go to previous screen
MINUS	Decrease value

Boiler Status

Fan Speed – Actual, Low, IGN, High

Flame

Signal Failures


Ignition Attempts Successful Failed

Boiler Run Time CH – hours DHW – hours


Blocking Errors (non-volatile memory for 16)

Locking Errors (non-volatile memory for 16)












(Menu & Enter Buttons – 4 seconds)





(Menu & Enter Buttons – 4 seconds) Installer Menu **Boiler Status Boiler Config CH Settings DHW Settings** Cascade Settings System Test Key Description Reset Control / System RESET MENU Enter / Exit user menu ENTER Select Menu item Confirm new parameter value

Scroll up to next menu item

Scroll down to next menu item

Go to next screen

Go to previous screen

Increase value

Decrease value


PLUS

MINUS

Cascade Settings Emergency Setpoint Start Delay Time Stop Delay Time Start Boiler Differential **Stop Boiler Differential Calculated Setpoint: Max Offset Up Calculated Setpoint: Max Offset** Down Next Boiler Start Rate Next Boiler Stop Rate **Rotation Interval Boilers for DHW Start Modulation Delay Factor** System Pump – Post Pump Time



(Menu & Enter Buttons – 4 seconds)



System Test

Кеу	Description
RESET	Reset Control / System
MENU	Enter / Exit user menu
ENTER	Select Menu item
	Confirm new parameter value
	Scroll up to next menu item
A	Go to next screen
PLUS	Increase value
	Scroll down to next menu item
▼	Go to previous screen
MINUS	Decrease value

System Test Settings

System test power: (Low, IGN, High)

Boiler Pump (On / Off)

CH Pump (On / Off)

DHW Pump (On / Off)



Error Code Troubleshooting



Error Code Troubleshooting




Current System Status

Error Description	n		Error Code #	1	1
Lockout Alarm GV Relay Error	A 0 5	Go to Page 40	Blocking Error Return Temp	E 4 0	Go to Page 46
Lockout Alarm Ignit Error	A 0 1	Go to Page 41	Blocking Error Low Water Cutoff	E 3 6	Go to Page 45
Lockout Alarm Blocking Too Long Error	A 0 0	Go to Page 40	F P Blocking Error False Flame Detect	E 3 5	Go to Page 44

Page # in IOM



Error Code Troubleshooting



- Flow chart design
- Easy to follow and understand
- Step by step procedure
- Error code listed in blue box



Combustion Requirements







 Combustion and proper installation set up required for all high efficiency models

- <u>Combustion Analyzer</u> Properly check CO² level of exhaust
- <u>Gas Meter</u> U-tube manometer or gauge set to check inlet gas pressure


•To change gas inlet pressure adjust at system regulator **NOT** THE GAS VALVE REGULATOR

•Sampling port located on Flue Collector

No need to drill sample port in flue pipe!!




Combustion: Built-in Sample Ports



UTIC4 BOILERS

Combustion Gas Valve on 50-200 models


Caa	C	00	
Gas	Min	Max	СО
Natural Gas	9.0	9.5	<200ppm
Propane	10.0	11.0	<200ppm



- •<u>Do not</u> adjust the gas regulator on the gas valve
- •Gas inlet pressure tap Natural: 3" – 13.5" w.c. LP: 5" – 13.5" w.c.
- •Throttle screw to adjust the air / gas mixture on the venturi assembly
- All gas pressure changes are done at the utility regulator external of the equipment



Combustion Gas Valve on 299 model



Gas	C	02	СО
	Min	Max	
Natural Gas	9.0	9.5	<200ppm
Propane	10.0	11.0	<200ppm

Throttle Screw (red)

Gas Inlet Pressure Tap



Maintenance/Cleaning





- Turn off gas and electrical
- Remove blower / burner assembly and examine flue passageways
- Remove igniter and sensor off top of heat exchanger
- Burner may be cleaned by using compressed air, nitrogen or CO₂ tank.



- Clean heat exchanger with nylon brush if required
- Any remaining sediment can be removed with a shop vacuum snorkel
- Re-install refractory and burner / gas valve
- •Visually inspect condensate trap re-fill trap (If required)





Critical Installation Points







Ū.



•Air in the system affects Low Mass Boilers differently than cast iron boilers

- •Heat Exchanger Water Volume is much lower
- •Air removal methods different
- •Water Flow rates are important
- •How does Antifreeze affect the System?
- •Clean Water





•Cast Iron Boilers are more tolerant of system air issues.

•Gravity works for us





Cast Iron Air Scoop

- Based on venturi principal; accelerated flow yields reduced pressure, causing dissolved gases to separate
- Slow Process Less Effective
- Proper location <u>Critical</u> for air scoop to remove air








Micro-Bubble Separator


•Based on the principal that reduced velocity plus multiple impact sites allow air bubbles to separate easily

- •Faster process, much more effective
- Location Not Critical for Separator to function













SSC Power Purge








- Low System Flow Rates will cause Boiler to heat quickly
- Cycles frequently on High Limit-Less Efficient
- Harder to get air out of boiler






Primary & Secondary Flow Balanced

Reduced Flow in Secondary (One Zone Calling)






(A) BOILES

Water Source

- Treated (Softened) water can reduce circulator capacity by 10-15% !!
- •If reduced flow rate is causing noise issues a higher head pump may resolve the problem.








Flush & Clean



- •Water quality can affect system performance
- •Dirty brackish water can lower boiling point
- •Also makes air removal more difficult











 The Point of no Pressure Change is the one place in the system where the pump cannot affect the overall system pressure.












How can pump placement affect system performance?

Supply vs. Return side Pumping



A typical residential circulator will develop about 6psi. In this diagram, all of the pump's differential pressure is on the outlet side.

6 psi differential - water flows






Because the point of no pressure change (the place that must remain at the 12 psi static fill pressure) is now halfway around the system, the pump is showing half of its pressure differential as an increase and the other half as a decrease. You now have a drop of 3 psi at its discharge.

Water flows exactly as it did in the last example because there's still a 6 psi pressure differential across the pump (15 psi - 9 psi = 6 psi differential).


6 psi differential – water flows





Because the outlet of the pump is right at the point of no pressure change, ALL of the pumps difference is on the inlet side. We still have a 6 psi difference and water flows as before.

6 psi differential – water flows






- The Water flowed in all 3 examples
- So why does pump placement matter?






BOILERS









With pump located on return what happens to the pressure at "X" when the pump starts?












- •If existing system is contributing to air removal difficulties raise the boiling point.
- •Increase system pressure to 20 psi.
- •Remember to pump the Expansion tank!
- •If higher pressure needed change Boiler relief to 50 psi and increase system pressure further.
- •Remember to pump the Expansion tank!



Normal Tank Operation




System Off

System Pressure=12

Tank Pressure=12




Normal Tank Operation






Normal Tank Operation





What happens if I don't Pump Up my Tank?




System Off

System Pressure=12

Tank Pressure=12




What happens if I don't Pump Up my Tank?





What happens if I don't Pump Up my Tank?





Antifreeze



- •Antifreeze is more viscous. Pump capacity reduced.
- •Thermal transfer capability reduced 17% at 50-50 strength.
- •Only use what's necessary.
- •Use tester to determine proper level.





Utica SSC Warranty

- 15 Year ECR Limited Warranty
- One Year all other parts



FIRST YEAR HEAT EXCHANGER ADDITIONAL COVERAGE Effective June 1, 2011

The SSC boiler utilizes our most innovative heat exchanger design that provides industry leading efficiency and reliability. It consists of a wide diameter stain-less steel tube with laser welded heat transfer fins that provide for the greatest heat transfer. The SSC heat exchanger is designed to endure the most challenging applications and guard against compromised water conditions that cause other boilers











Technical Support



1-800-325-5479 Or **1-800-253-7900**



www.uticaboilers.com





www.uticaboilers.com

Thank You